


Effective Dishwashing Tips

Ensure both wash and rinse arms are spinning during their cycles.

For best results empty water when soiled. Rinse tank and refill.

Wash temperature should be 55-65 °C. Rinse temperature should be 82-85 °C.

Remove excess food deposits.



Do not overload cutlery basket



Stack plates & trays only in clear rows



Stack cups and bowls facing down

e: customerservices@westernhygiene.ie

t: IRL 1850 50 55 55 UK 0845 4503 703

w: www.westernhygiene.ie

Material
Safety
Data
Sheets

Full first aid advice is contained in the MSDS available online at www.westernhygiene.ie

Western Hygiene
Solutions