# **Effective Dishwashing**


- Check wash temperature should be 55-65 degrees & rinse temperature is 82-85 degrees
- Use the correct detergent & ensure that there is detergent in the cartridge
- · Remove any loose soil before washing.
- Check to see if dosing pump operates during cycle.
- Ensure pipes from dosing system to machine are not kinked or blocked.
- On sounding the alarm replace the detergent cartridge
- Only authorised users should change the detergent cartridge & always note the hazard label.
- Stack cups, bowls & pots bottom up & don't double stack crockery.
- Never open the dishwasher door during the cycle.
- Keep the dishwasher clean. Remove water & clean filters daily.
- Report any machine faults to your supervisor.
- Always allow crockery to air dry.
- Full first aid advice is contained in MSDS available on www.westernhygiene.ie

## First Aid in the event of accidents



#### Chemical burn of eyes:

Rinse out your eyes with plenty of water immediately for at least ten minutes opening your eyes/eyelids widely.





#### Chemical burn of skin:

Take off soiled/contaminated clothing immediately. Wash affected skin parts thoroughly with plenty of water. Use sterile wound dressing if possible. Seek medical advice.











Chemical burn of mouth, gullet or stomach: Rinse out your mouth and drink one glass of water. Do not cause vomiting.

Seek medical advice immediately & show the doctor the label of the product



### Chlorine gas poisoning:

Open windows, leave the room. Seek medical advice immediately.



**Step 1: (Neodisher Special Plus)** 

Unplug the detergent pump or remove the pipe from the detergent drum.

Step 2: (Maintenance – Every 2 weeks)

Add 10mls of descaler per every litre of water capacity of the dishwasher into the water tank deposit.

#### Step 3:

Make 5 empty washes. For dishwashers with continuous running cycles, let the machine run empty for 10 minutes.

#### Step 4:

**Empty the water tank.** 

#### Step 5:

Make 2-3 other empty washes or run the machine for 5 minutes for dishwashers with continuous running cycles.

#### Step 6:

**Empty the water tank.** 

#### Step 7:

Fill in the water tank.

### Step 8:

Plug in the detergent pump or put the pipe into the detergent drum

### Step 9:

Start washing as usual.



Wear suitable safety gloves!



Hygiene + Healthcare Products

Wear suitable eye protection!





www.westernhygiene.ie info@westernhygiene.ie













